

955 Benton Ave., Winslow, ME 04901 • Phone: 1-877-564-6697 • Fax: 1-800-738-6314
Email: service@johnnyseeds.com • Website: Johnnyseeds.com

PARTS INCLUDED

- Wooden Handle

Model #7156

- Rake Head without support arms (folded for shipping)
- (1) #8 x $\frac{3}{4}$ " screws

Model #9219

- Rake Head with support arms (folded for shipping)
- (2) #8 x $\frac{3}{4}$ " screws

REQUIRED FOR ASSEMBLY


- 6-Point Box End Wrench or Socket Wrench, Size 10 mm
- Phillips Head Screwdriver



ASSEMBLING YOUR RAKE FOR BOTH #7156 AND #9219 MODELS

1. Fasten the rake head to the handle using the $\frac{3}{4}$ " wood screw provided.
2. Loosen the bolts on the top of the rake head so you will be able to adjust it to your desired angle. Note: Exact wrench size is recommended to avoid stripping the bolts.
3. Adjust the rake head to your desired angle and tighten bolts to hold it in place.

Note: You may want to bring a wrench to the garden with you and experiment until you find the most comfortable setting for your body type and the job you are performing.



For Model #9219

4. Fasten the support arms using the remaining $\frac{3}{4}$ " wood screw and a Phillips head screwdriver.

(Model #7156 does not have support arms.)

