


PAPERPOT DROP SEEDER PLATES COMPARISON CHART

Paperpot Drop Seeder

Seed an entire Paperpot tray in seconds.

Drop seeder system comprised of interchangeable plates that sit within a frame. Clear plexiglass plates for easy alignment over Paperpot cells. Only compatible with 264 cell Paperpot trays and chain pots. **Frame and plates sold separately.**





Skip Plates are used to seed every other cell, allowing you to double the in-row spacing of the chain pots used.

Paperpot Drop Seeder Plates

Part #	Description	# Holes	Hole Size	In-Row Spacing*	Recommended Crops
7954	2.8 mm Plate	264	2.8 mm	2", 4", 6"	Arugula, Kohlrabi, Leeks, Lettuce (raw, mini head), Mustard, Pac Choi, Basil, Parsley, Larkspur
7955	3.2 mm Plate	264	3.2 mm	2", 4", 6"	Onion (raw), Shallot, Turnip, Dill, Dianthus (pelleted), Stock
7956	3.5 mm Plate	264	3.5 mm	2", 4", 6"	Brussels Sprouts, Radish, #12.5 Pelleted Seed
7957	4.5 mm Plate	264	4.5 mm	2", 4", 6"	Spinach, Daikon Radish, #13 Pelleted Seed, Agrostemma, Cynoglossum, Didiscus
7958	6.0 mm Plate	264	6.0 mm	2", 4", 6"	Beets, Swiss Chard, Cilantro, Leaf Fennel, Orlaya, Sweet Peas
8326	2.8 mm Skip Plate	132	2.8 mm	8", 12"	Cabbage, Cauliflower, Kale, Lettuce (raw, full-size head), Phlox
8327	3.2 mm Skip Plate	132	3.2 mm	8", 12"	Broccoli, Chicory (raw), Collards

^{*}In-row spacing varies depending on Paper Chain Pots used.