

PAPERPOT DROP SEEDER PLATES COMPARISON CHART


Paperpot Drop Seeder

Seed an entire Paperpot tray in seconds.

Drop seeder system comprised of interchangeable plates that sit within a frame. Clear plexiglass plates for easy alignment over Paperpot cells. Only compatible with 264 cell Paperpot trays and chain pots. **Frame and plates sold separately.**



Paperpot Seeder Frame 7953



Skip Plates are used to seed every other cell, allowing you to double the in-row spacing of the chain pots used.

Paperpot Drop Seeder Plates

Part #	Description	# Holes	Hole Size	In-Row Spacing*	Recommended Crops
7954	2.8 mm Plate	264	2.8 mm	2", 4", 6"	Vegetables: arugula, kohlrabi, leeks, mini head lettuce (raw), mustard, onions, pac choi; Herbs: basil, parsley; Flowers: larkspur
7955	3.2 mm Plate	264	3.2 mm	2", 4", 6"	Vegetables: onion (raw), shallot, turnip; Herbs: dill; Flowers: dianthus (pelleted), stock
7956	3.5 mm Plate	264	3.5 mm	2", 4", 6"	Vegetables: brussel sprouts, radish, #12.5 pelleted seed
7957	4.5 mm Plate	264	4.5 mm	2", 4", 6"	Vegetables: spinach, diakon radish, #13 pelleted seed; Flowers: agrostemma, cynoglossum, didiscus
7958	6.0 mm Plate	264	6.0 mm	2", 4", 6"	Vegetables: beets, Swiss chard; Herbs: cilantro, leaf fennel; Flowers: orlaya, sweet peas (flower)
8326	NEW 2.8 mm Skip Plate	132	2.8 mm	8", 12"	Vegetables: cabbage, cauliflower, kale, full-size head lettuce (raw); Flowers: phlox
8327	NEW 3.2 mm Skip Plate	132	3.2 mm	8", 12"	Vegetables: broccoli, chicory (raw), collards

*In-row spacing varies depending on Paper Chain Pots used.