


Hatfield Transplanters: 1.5", 2.0", and 2.5" Models Assembly Instructions



955 Benton Ave., Winslow, ME 04901 • Phone: 1-877-564-6697 • Fax: 1-800-738-6314 Email: service@johnnyseeds.com • Web Site: Johnnyseeds.com



Copyright © 2016 Johnny's Selected Seeds. All rights reserved.

Assembly:

<u>Step 1</u>:

Remove hinge bolts (J) from the bottom assembly (F).

<u>Step 2</u>:

Attach strapped shaft (C) and depth control stop plate (D) to outside of bottom assembly (F) with two shaft bolts (E). Nuts should face out.

<u>Note</u>: Depth control stop plate is adjusted for desired planting depth by sliding up & down along the bottom shaft bolt.

<u>Step 3</u>:

Re-attach hinge flap (K) to bottom assembly (F) using the hinge bolts (J) removed in step one. Do not tighten completely. Pivot shaft (I) and hinge flap should move smoothly on hinge bolts.



Operation:

- One person operates the transplanter, another handles the seedlings.
- Hold handles apart.
- Plunge into soil to the depth stop.
- Push handles together.
- Drop transplant into the seedling chute.
- Lift the transplanter straight up.
- Firm soil around the seedling with a foot.
- Follow up with some water and you are done.

Made in Taiwan Patent #6,659,028 B1

Step 4:

Insert handles (A)

shafts (C & I) and

(G) into bottom

assembly (F).

as desired for

into their respective

slide seedling chute


Adjust handles (A)

height and tighten

strap bolt (B) and

handle bolt (H) to

complete assembly.



н G С

REV 01/28/2016 RP, rc

Copyright © 2016 Johnny's Selected Seeds. All rights reserved.