




955 Benton Ave., Winslow, ME 04901 • Phone: 1-877-564-6697 • Fax: 1-800-738-6314
Email: service@johnnyseeds.com • Web Site: Johnnyseeds.com



The Double Rolling Dibbler is used to make impressions in the soil for more precisely spaced row crops. Straight and even plantings are easier to cultivate and more productive, resulting in less labor and more profit. The dibles are easily adjustable for several in-row spacing options, and effective for puncturing through plastic mulch.


A diversity of in-row spacing options can be achieved by securing the desired dibles to the outside of the wheel while fastening the spare dibles facing inward when not in use. The two wheels can also be mounted in several ways to achieve different spacings between rows.

Made in Vermont. Additional Rolling Dibbler models are also available.



PARTS INCLUDED

- A. (1) Wooden Dowel Handle
- B. (1) Wooden Handle Shaft
- C. (1) Wheel Axle
- D. (1) 1/4"-20 x 3" Hex Bolt
- E. (2) 1/4" Flat Washers
- F. (1) 1/4" Nylock Nut
- G. (2) Wheels
- H. (2) Cotter Pins
- I. (32) Aluminum Dibles
- J. (32) 1/4"-20 x 5/8" Bolts



ADDITIONAL TOOLS NEEDED

- Set of 7/16" wrenches or sockets
- Flat-head screwdriver

ASSEMBLY



1. Insert dowel handle into opening at the top of the handle shaft, lining up the holes.

Note: The hole in the dowel is located to one side for creating an off-set handle orientation. The short handle end should be protruding from the side of the handle with the Dibbler logo stamped on it.


2. Insert the hex bolt provided through the holes. Be sure there is a washer on either side of the wood handle before securing the nylock nut. See left.
3. Insert the wheel axle into the T-shaped connector at the end of the handle. See right.



Copyright © 2018 Johnny's Selected Seeds. All rights reserved.

- Place the wheels onto either end of the axle and secure with the cotter pins provided. See right.

Note: The wheels have a side with a metal bracket and one without, and can be mounted onto the axle either way, depending on your desired row spacing. See spacing options below.




INSTRUCTIONS FOR USE

Rolling Dibblers can be either pushed or pulled. Make sure the plastic wheel hubs sit directly on the soil surface and the metal dibbles fully penetrate the ground.


NOTE: The spacing accuracy of the dibbles can vary depending upon rolling speed and soil conditions. Always measure the spacing to be sure it is correct before planting your crops. Dibble holes may be difficult to see in dry and sandy soils.

WHEEL SPACING


The Dibbler's wheels can be mounted onto the axle with the red metal bracket facing inward or outward to achieve different spacing between wheels. See below.



8" Wheel Spacing
Both metal brackets facing outward.



10" Wheel Spacing
One metal bracket facing outward, one facing inward.



12" Wheel Spacing
Both metal brackets facing inward.

DIBBLE SPACING

The Dibbler's strong, aluminum alloy wheels can be easily changed out using a flat-head screwdriver. Store dibbles facing inward on the wheels when not in use. The user can also set up the two wheels so that the dibbles are offset from one another for additional plant spacing.

See the following page for basic in-row spacing options.



DIBBLE SPACING OPTIONS



3" Spacing
All dibbles on the 3 holes



4" Spacing
Dibbles on the 4 holes only



6" Spacing
Dibbles on every other 3 hole



8" Spacing
Dibbles on every other 4 hole



12" Spacing
Dibbles on the 4 "corners"



15" Spacing
Dibbles on every 4th 4-3 hole



22" Spacing
2 Dibbles on opposite sides



41" Spacing
1 Dibble anywhere

The holes drilled into the plastic wheel hub feature a numbering system for interpreting whether the dibbles are being spaced in 3" or 4" increments.



11/09/2018 JG/ms